

## Required Elements for Dry Wells

### Feasibility

#### Required Elements

- To be suitable for infiltration, underlying soils shall have an infiltration rate ( $f_c$ ) of at least 0.5 inches per hour, as initially determined from NRCS soil textural classification, and subsequently confirmed by field geotechnical tests (see Appendix D). The minimum geotechnical testing is one test hole per 5000 sf, with a minimum of two borings per facility (taken within the proposed limits of the facility).
- Soils shall also have a clay content of less than 20% and a silt/clay content of less than 40%.
- Infiltration practices cannot be located on areas with natural slopes greater than 15%.
- Infiltration practices cannot be located in fill soils, except the top quarter of an infiltration trench or dry well.
- To protect groundwater from possible contamination, runoff from designated hotspot land uses or activities must not be directed to a formal infiltration facility. In cases where this goal is impossible (e.g., where the storm drain system leads to a large recharge facility designed for flood control), redundant pretreatment must be provided by applying two of the practices listed in Table 5.1 in series, both of which are sized to treat the entire  $W_{Qv}$ .
- The bottom of the infiltration facility shall be separated by at least three feet vertically from the seasonally high water table or bedrock layer, as documented by on-site soil testing. (Four feet in sole source aquifers).
- Infiltration facilities shall be located at least 100 feet horizontally from any water supply well.
- Infiltration practices cannot be placed in locations that cause water problems to downgradient properties. Infiltration trenches and basins shall be setback 25 feet downgradient from structures and septic systems. Dry wells shall be separated a minimum of 10 feet from structures.

### Conveyance

#### Required Elements

- The overland flow path of surface runoff exceeding the capacity of the infiltration system shall be evaluated to preclude erosive concentrated flow during the overbank events. If computed flow velocities exceed erosive velocities (3.5 to 5.0 fps), an overflow channel shall be provided to a stabilized watercourse. (See Appendix L for erosive velocities of grass and soil).
- All infiltration systems shall be designed to fully de-water the entire  $W_{Qv}$  within 48 hours after the storm event.
- If runoff is delivered by a storm drain pipe or along the main conveyance system, the infiltration practice must be designed as an off-line practice (see Appendix K for a detail), except when used as a regional flood control practice.

### Pretreatment

#### Required Elements

- A minimum pretreatment volume of 25% of the  $W_{Qv}$  must be provided prior to entry to an infiltration facility, and can be provided in the form of a sedimentation basin, sump pit, grass channel, plunge pool or other measure.
- If the  $f_c$  for the underlying soils is greater than 2.00 inches per hour, a minimum pretreatment volume of 50% of the  $W_{Qv}$  must be provided.
- If the  $f_c$  for the underlying soils is greater than 5.00 inches per hour, 100% of the  $W_{Qv}$  shall be pretreated prior to entry into an infiltration facility.

- Exit velocities from pretreatment chambers shall be non-erosive (3.5 to 5.0 fps during the two-year design storm). (See Appendix L for erosive velocities of grass and soil).

### **Pretreatment Techniques to Prevent Clogging**

Infiltration basins or trenches can have redundant methods to ensure the long-term integrity of the infiltration rate. The following techniques are pretreatment options for infiltration practices:

- Grass channel (Maximum velocity of 1 fps for water quality flow. See the Fact Sheet on page 5-10 for more detailed design information.)
- Grass filter strip (minimum 20 feet and only if sheet flow is established and maintained)
- Bottom sand layer (for I-1)
- Upper sand layer (for I-1; 6" minimum with filter fabric at sand/gravel interface)
- Use of washed bank run gravel as aggregate
- Alternatively, a pre-treatment settling chamber may be provided and sized to capture the pretreatment volume. Use the method prescribed in section 6.4.3 (i.e., the Camp-Hazen equation) to size the chamber.
- Plunge Pool
- An underground trap with a permanent pool between the downspout and the dry well (I-3)

### Treatment

#### Required Elements

- Infiltration practices shall be designed to exfiltrate the entire  $W_{Qv}$  through the floor of each practice (sides are not considered in sizing).
- The construction sequence and specifications for each infiltration practice shall be precisely followed. Experience has shown that the longevity of infiltration practices is strongly influenced by the care taken during construction
- Calculate the surface area of infiltration trenches as:

$$A_p = V_w / (nd_t)$$

Where:

- $A_p$  = surface area (sf)
- $V_w$  = design volume (e.g.,  $WQ_v$ ) (ft<sup>3</sup>)
- $n$  = porosity (assume 0.4)
- $d_t$  = trench depth (maximum of four feet, and separated at least three feet from seasonally high groundwater) (ft)

- Calculate the approximate bottom area of infiltration basins using the following equation:

$$A = v_w/d_b$$

Where:

- $A$  = surface area of the basin (ft<sup>2</sup>)
- $d_b$  = depth of the basin (ft)

Note that in trapezoidal basins, this area should first be used to approximate the area at the bottom of the basin, but can later be modified to account for additional storage provided above side slopes.

### Landscaping

#### Required Elements

- Upstream construction shall be completed and stabilized before connection to a downstream infiltration facility. A dense and vigorous vegetative cover shall be established over the contributing pervious drainage areas before runoff can be accepted into the facility.
- Infiltration trenches shall not be constructed until all of the contributing drainage area has been completely stabilized.

### Maintenance

#### Required Elements

- Infiltration practices shall never serve as a sediment control device during site construction phase. In addition, the Erosion and Sediment Control plan for the site shall clearly indicate how sediment will be prevented from entering an infiltration facility. Normally, the use of diversion berms around the perimeter of the infiltration practice, along with immediate vegetative stabilization and/or mulching can achieve this goal.
- An observation well shall be installed in every infiltration trench and dry well, consisting of an anchored six- inch diameter perforated PVC pipe with a lockable cap installed flush with the ground surface.
- Direct access shall be provided to infiltration practices for maintenance and rehabilitation. If a stone reservoir or perforated pipe is used to temporarily store runoff prior to infiltration, the practice shall not be covered by an impermeable surface.

Figure 6.13 Dry Well (I-3)

